

## JB74 oil catch tank

Thank you very much for purchasing our product.

Please be sure to install the product at a place such as a pro shop where you have the knowledge, skills, qualifications, and terminology.

If you are not confident in the installation, or if you do not understand this manual, please do not install it. We cannot accept complaints from such people.

We are not responsible for any accidents that may occur after installation, so we appreciate your understanding and understanding.

By starting the installation, you are deemed to have agreed to the contents of this manual.

set content

Oil catch tank body, tank stay, hose (cut and used), 4 hose bands, 8 $\frac{1}{2}$  elbow pipe (for water hose)

1 $\frac{1}{2}$  joint pipe, other bolts and nuts



The catch tank body is installed behind the ABS on the left side of the vehicle. When you remove the blow-by pipe, the water pipe also comes off.

Use one ABS fixing bolt. Then, connect the water hose with the included 8 $\frac{1}{2}$  elbow pipe.

The IN hose from the engine and the OUT hose go to the intake pipe. Use the genuine hose clip as is.



Insert the included 1 $\frac{1}{2}$  joint pipe into the intake hose. Use the genuine hose clip as is.



The hose band for the hose connected to the oil catch tank is included. use things

Once every 5,000km to 10,000km, remove the upper side of the oil catch tank side volume check hose, point it downward, and discard the liquid that has accumulated inside.

Please check it out. The hose can be easily removed by pushing up on the insertion port and pulling on the hose.

Seller (inquiries only available by phone) 254-1

Taishinarami, Kumiya-cho, Kuse-gun, Kyoto Prefecture

high bridge first

TEL 0774-48-1167